



ALTREK INDUSTRIES LTD.

P.O. Box 822, 138 Fisher Street,

Okotoks, Alberta, T1S 1A9

Phone: (403)938-2448

Fax: (403)938-6563

Email: altrek@telus.net

Web: www.altrekproducts.com

SHOWER CAP INSTALLATION GUIDELINES

1. Set the CAP on top of the compatible unit
2. Make sure that the cap sits evenly on all 3 sides
3. Drill a 1/8" hole in all 4 corners of the cap
4. Put the supplied Stove Bolt through the holes and fasten until tight with the supplied nut.

**Please find enclosed with this guideline: 4 BOLTS and 4 NUTS
to be used for installation of the ALTREK CAP**